



## ZOMBIE

### Navigate To:

- [What Is Zombie Auto-Aim Mod?](#)
- [How Does Zombie Auto-Aim Mod Work?](#)
- [How Do I Operate Zombie Auto-Aim Mod?](#)
- [What Games Is Zombie Auto Aim Mod Compatible With?](#)

### What Is Zombie Auto-Aim Mode?

Zombie Auto Aim Mode was specially designed for Call Of Duty series such as Zombie in Black Ops and Campaign in Modern Warfare 2 and 3.

### How Does Zombie Auto-Aim Mode Work?

Zombie mode allows you to auto-aim to the nearest zombie's chest or head while scoping your rifle. Anytime you pull out Left Trigger to aim, it's going to lock under the nearest zombies head.

### How Do I Operate Zombie Auto-Aim Mod?

First, you must turn the Zombie/Auto Aim ON.

#### To enable/disable the mod on your controller:

- **Hold the mod switch, then press and hold the Right Bumper (In Default Button Layout), and then tap The Left Trigger (ADS/scope button in default button layout). LED3 or LED4 will illuminate to let you know zombie auto-aim is active.**
- **Pull your scope-weapon button like normal to aim and move the target near a zombie, the mod will pulse the scope-weapon button and cause the crosshairs to lock onto the nearest zombie.**

You can always turn all exclusive mods OFF (Player 3 and 4 LED's) by holding down mode switch on the back and tapping A Button.

### What Games Is Zombie Auto Aim Mod Compatible With?

Zombie Mod is compatible with Call of Duty games such as Campaign in Modern Warfare and Ghosts; Zombie mode in Black Ops 1, 2 and 3. NOTE: Zombie mod is not compatible with AW Zombie.