



ZOMBIE

Navigate To:

- [What Is Zombie Auto-Aim Mod?](#)
- [How Does Zombie Auto-Aim Mod Work?](#)
- [How Do I Operate Zombie Auto-Aim Mod?](#)
- [What Games Is Zombie Auto Aim Mod Compatible With?](#)

What Is Zombie Auto-Aim Mod?

Zombie Auto Aim Mod was specially designed for Call Of Duty series.

How Does Zombie Auto-Aim Mod Work?

Zombie mod allows you to auto-aim to the nearest zombie's chest or head while scoping your rifle. Anytime you pull out Left Trigger to aim, it's going to lock under the nearest zombies head.

NOTE : For COD Black Ops 2, make sure Aim Assist Feature is DISABLED.

How Do I Operate Zombie Auto-Aim Mod?

To **enter Zombie Mod on your controller**, hold the mod switch on the back of the controller and tap your throw-tactical button (L2 Button in default button layout). The Player 4 LED will twinkle, and then stay ON to let you know Zombie Auto-Aim Mode is ready.

To **change to a different Zombie Sub Mode**, hold the mod switch on the back of the controller and hold throw-tactical button (L2 Button in default button layout), then count the number of blinks on the Player 4 LED. (Example: Sub Mode 2-Player 4 LED flashes 2 times and stays LIT).

Two different Zombie Sub Modes are available as follows:

Mode	Notes
Mode 1	Zombie auto-aim, but with Rapid Fire disabled
Mode 2	Zombie auto-aim plus Rapid Fire enabled

To **turn Zombie Mod OFF**, hold the mod switch on the back of the controller and tap D-pad down. Player 4 LED will twinkle and then turn OFF.

What Games Is Zombie Auto Aim Mod Compatible With?

Zombie Mod is compatible with Call of Duty games such as Campaign and Zombie modes in Black Ops 3, Ghosts, Modern Warfare and Zombies in Black Ops 1, 2. It is not compatible with AW Zombie.