



## LAYOUTS

### Navigate To:

- [What are Selectable Button Layouts?](#)
- [How do Selectable Button Layouts work?](#)

### What are Selectable Button Layouts?

This mod supports more than just the standard button layouts. Rapid fire, drop shot, fast reload - all of the features of the modchip will now work on your favorite button layout. Just remember to tell the mod chip what button layout you want by setting the appropriate mode from the list above.

### How do Selectable Button Layouts work?

To switch to a different button layout:

- **Hold mod switch + tap Sync button to enter the mod programming menu. All four LED's will turn white, and wait for you to enter a selection.**
- **Press the Button Y to change your button layout. All four LED's will turn white, and wait for you to enter a selection. The mod will blink all four LED's in white to confirm that you are now about to change your button layout.**
- **Press right trigger to go to the next button layout. Press left trigger to go to the previous button layout.**
- **Tap the mod switch to save your selection. All four LED's blink three times to confirm that your selection was saved.**

The five default configurations are as follows:

- **Layout 1: Default**
- **Layout 2: Tactical**
- **Layout 3: Lefty**
- **Layout 4: Nom4d**
- **Layout 5: Nom4d Tactical**

***NOTE :*** *Some mods don't work correctly when in the Nom4d layouts*