

MEGA MODZ FAST RELOAD MOD FOR PLAYSTATION CONTROLLER

You're about to read the latest and up-to-date PS4 Pro Modded Controller instructions. If you've purchased your controller before 1/14/2019 then visit the [archived page](#) as you may not happen to have the updated version.

This article contains the following sections:

- **[At Glance](#)**
- **[Turning the Mod ON & OFF](#)**
- **[Checking Current Sub-Mode](#)**
- **[Changing Sub-Modes](#)**
- **[Setting Up Custom Values](#)**
- **[Compatible Games](#)**

AT GLANCE

Fast Reload can technically be called a glitch in the Call of Duty games. When you press the reload button (Square), your character begins to reload. The ammo clip bar will actually reach a full bar before the animation sequence of the reloads is done. If you hit your "Change Weapon" button (Triangle) twice very quickly just after the ammo reaches a full bar, but before the animation sequence has completed, you can start firing again sooner than your opponent. Thus you have just completed a "Fast Reload" because it's faster than letting the full reload animation sequence play out. Getting the timing down perfectly is very difficult. This is where the Fast Reload feature of our modded controller comes into play. It will automatically wait out this delay and press the "Change Weapon" button for you just at the right time.

There are a few things to keep in mind:


- **Fast Reload offers 10 sub-modes and 3 different configurations that work differently. Choosing the right sub-mode for the game you play is critical.**
- **There is no such thing as a universal Fast Reload sub-mode. Depending on the gun you play with, each sub-mode has to be configured with custom timing.**
- **Fast Reload will cut reloading time by roughly 30% from normal reloading. Let's say if the average reloading time for Assault Rifle in COD games is 4 seconds, the Fast Reload feature will reload your gun as soon as 2.8 seconds.**

IN-DEPTH


Turning the Mod ON & OFF

To turn the Mod ON


- Hold the mod switch and then tap the Square button.




1 STEP. HOLD DOWN MOD BUTTON



1 STEP. HOLD DOWN MOD BUTTON




2 STEP. TAP SQUARE BUTTON




2 STEP. TAP SQUARE BUTTON

One of the open LEDs will glow in BLUE indicating that a special feature has been activated.

FAST RELOAD Blue



FAST RELOAD Blue



- Fast Reload is now primed and ready to go. To perform a Fast Reload, press the reload button (Square). The modchip will take over and perform the special Fast Reload every time you press the reload button.


Be sure to tune in the timing for your particular gun (see below).

Want to learn more about how LED MOD Indicator works? [Click here](#)


To turn the Mod OFF

The mod can be turned OFF the same way it has been turned ON (see above).


The mod can be turned OFF the same way it has been turned ON (see above). Modes located on 2 - 4 LED Indicator slots (Including Fast Reload) can be turned OFF all at once by holding down the mod button on the back and tapping the button X.




1 STEP. HOLD DOWN MOD BUTTON



1 STEP. HOLD DOWN MOD BUTTON



2 STEP. TAP X BUTTON




2 STEP. TAP X BUTTON

All 2, 3, and 4 LEDs will turn off indicating that all special features have been turned OFF.


Checking Current Sub-Mode

The mod offers 10 sub-modes. You can always check what sub-mode you have currently active by following these steps:


- Make sure the Fast Reload mod is ON.
- Hold down the mod button on the back.
- Hold down the Square button for 3 seconds.




1 STEP. HOLD DOWN MOD BUTTON



1 STEP. HOLD DOWN MOD BUTTON



2 STEP. HOLD DOWN SQUARE BUTTON FOR 3 SEC




2 STEP. HOLD DOWN SQUARE BUTTON FOR 3 SEC

The LED indicator will flash all 4 slots in WHITE indicating that the modchip has entered a sub-mode checking menu. It will then show the number of a sub-mode you have currently active:

- **1ST Sub-mode - 1 Red LED, the top left LED slot is taken**
- **2ST Sub-mode - 2 Red LEDs, top left and right slots are taken**
- **3RD Sub-mode - 3 Red LEDs, top left, top right, and bottom left slots are taken**
- **4TH Sub-mode - 4 Red LEDs**
- **5TH Sub-mode - Top Left is in Green, and all the rest are in Red**
- **6TH Sub-mode - Top Left and Right are in Green, and the bottom Left and Right are in Red**
- **7TH Sub-mode - All LEDs are in Green except for the 4th (bottom right) 4th one is in Red**
- **8TH Sub-mode - 4 Green LEDs**
- **9TH Sub-mode - Top Left in Blue, all the rest are in Green**
- **10TH Sub-mode - Top Left and Right are in Blue, and Bottom Left and Right are in Green**

Sub-Mode Number is 1



Upon checking the sub-mode, the modchip will automatically take you to the place you were before in 3 seconds. You are welcome to expedite the process by pressing the mod button on the back and exiting the sub-mode menu.

Want to learn more about the Sub-Modes Indication? [Click here](#)

Changing Sub-Modes

To change Fast Reload sub-modes, you will have to go thru the sub-mode checking menu first (see above):

- **Hold down the mod button on the back.**
- **Hold down the Square button for 3 seconds.**

The LED indicator will flash all 4 slots in WHITE showing that the modchip entered the sub-mode menu. It will then show the number of sub-mode you have active currently.

- Use the R2 button to increase the number of sub-mode or use the L2 button to go down on a sub-mode.
- To save the setting, you will have to press the Mod Button.

NOTE: Keep in mind, there is a “3-second rule” that applies every time you check or change sub-modes. If you’ve been inactive for more than 3 seconds, the modchip will exit the sub-mode menu automatically.

TIP: There is a “Quick Sub-Mode Scroll” option available on every Mega Modz Controller allowing you to get to the desired sub-mod quickly and avoid waiting for the modchip to go through the sequence of sub-modes. Quickly tapping the R2 button a number of times increase the sub-mode number by the number of times the R2 button was tapped, getting you to the desired sub-mode rapidly. Quickly tapping the L2 button a number of times decrease the sub-mode number by the number of times the L2 button was tapped, getting you to the desired sub-mode instantly. Example: You have sub-mode number 1 active, tapping the R2 button 2 times quickly will take you to sub-mode #3. Tapping on the R2 button 5 times quickly will take you to sub-mode #6.

There are 10 sub-modes available:

Sub-Modes	Unit Delays	Modern Warfare Weapons
1	42	Assault Rifles: AK-47
2	48	Assault Rifles: Killo 141, M4A1, M13 Marksman Rifles: EBR-14
3	52	SMG's: Uzi, MP7
4	53	Assault Rifles: FN Scar 17
5	58	SMG's: AUG
6	59	Assault Rifles: FR 5.56 SMG's: PP 19 Bizon
7	62	SMG's: MP5
8	80	LMG's: SA 87
9	208	LMG's: M92
10	231	LMG's: PKM

NOTE: The latest software update that has been released on 2/5/2020 eliminates the need for configuring unit delays in programming mode. All 10 sub-modes are already preset for Modern Warfare Guns.

NOTE: The timing for each mode can be custom-tuned for your specific gun via a programming mode (see diagrams below). You must select the right sub-mode depending on the game you play and enter the correct Fast Reload unit delay time for your gun. One unit delay is 10 ms (1UD = 10ms)

NOTE: Fast Reload does not work on some shotguns or sniper rifles. Fast Reload only works on guns that have a clip - it will not work on guns where the bullets are loaded one at a time. There are several different factors that affect Fast Reload, including

the attachments that you select. An attachment such as Fast Mag will actually change the Fast Reload timing. Different guns have different Fast Reload settings, and if you have the Fast Mag attachment selected, your Fast Reload timings will change again. It's recommended to trade for any other attachment rather than using Fast Mag while having Fast Reload mod ON.

LIMITATION: *Fast Reload and Auto Heal mods cannot be used simultaneously, therefore it won't let the user activate them both at the same time. Choosing one over another will replace one by another on the LED Mod Indicator.*

NOTIFICATIONS: *Mega Modz modchip technology notifies you when mods get turned ON and OFF. The modchip will send a signal to rumble motors anytime you activate or deactivate mods. The feature will allow you to focus on gameplay and keep your eyes on the screen without looking at the LED Indicator.*

Want to learn more about Mega Modz Haptic Technology? Click [Here](#)

Setting Up Custom Values

Don't like the pre-tuned speed we've provided? Create-your-own!

Fast Reload delays are programmed by individually setting the hundreds digit, the tens digit, and the one's digit. For example, if the reload delay is 105 units, "1" is the hundreds digit, "0" is the tens digit, and "5" is the ones digit.

If you haven't done so already, we strongly recommend learning how custom speeds indication works [here](#) before entering a "Programming Mode".

You've mastered the use of Fast Reload and you're ready to dial in your own custom Fast Reload speed. Fast Reload can accept a "delay number" from 0 through 255. Smaller numbers are for the weapons that naturally reload faster.

Let's begin!

- **Turn ON Fast Reload.**
- **Hold the mod switch on the back and then tap the PS4 Home button. All four LEDs will light up in WHITE to let you know that it's waiting for further input.**
- **Tap the Square button and the modchip will take you to the hundred digits slot. Let's say your values started at 130 unit delays. The mod will light up the "hundreds" digit on all 4 LEDs.**
- **Tap the R2 button to increase the "hundreds" digit or tap the L2 button to decrease the "hundreds" digit. The mod will blink LEDs to let you know what the current number is. When you're happy with the number →**
- **Tap the mod switch to move to the next number. Now we're at the "tens" digit and you can adjust the numbers here. Follow the procedure from above.**
- **Tap the L2 button to decrease the "tens" digit, and tap the R2 button to increase the "tens" digit.**
- **Tap the mod switch to save that digit and move to the "ones" place.**
- **Lastly, we're at the "ones" digit place. Follow the procedure from above to change the numbers (if needed) one last time.**

- Tap the L2 button to decrease the “ones”, and tap the R2 button to increase the “ones”.
- Tap the mod switch to save your selection. The mod will blink all 4 LEDs in red 3 times very quickly and exit the programming menu saving the last setting.

NOTE: The controller will always remember the last programming speed you have before powering down.

There is an “8-second rule” that applies every time you enter the “Programming Mode”. If you’ve been inactive for more than 8 seconds, the modchip will exit the programming menu automatically.

TIP: There is a “Quick Speed Scroll” option available on every Mega Modz Controller allowing you to get to the desired speed quickly and avoid waiting for the modchip to go through the sequence of speeds.

Quickly tapping the R2 button a number of times increase the speed number by the number of times the R2 button was tapped, getting you to the desired speed rapidly. Quickly tapping the L2 button a number of times decrease the speed number by the number of times the L2 button was tapped, getting you to the desired speed instantly.

Example: You have speed number 1 active, tapping the R2 button 2 times quickly will take you to speed 3. Tapping on the R2 button 5 times quickly will take you to speed 6.

If you would like to only check custom numbers then, after entering a programming mode and pressing the Square button, you can see the numbers in the slots without changing them by pressing the mod button and skipping the adjustment part.

It will look like this:

1. Turn ON Fast Reload Mod.
2. Enter a programming Mode.
3. Tap the Square button to get into Fast Reload custom speeds.
4. The first digit slot you’ll see is the hundreds. See the number and press the mod button.
5. The second digit slot is the tens. See the numbers and press the mod button.
6. The third digit slot is the ones. See the numbers and press the mod button to exit the programming menu.

Compatible Games

Fast Reload Mod is compatible with all recent Call of Duty games. It will also be compatible with future COD titles.

Happy shooting!

Having issues operating your Fast Reload Mod? Visit our [Help Desk](#) for troubleshooting.

Fast Reload Programming Unit Delays For COD MW:

Assault Rifles	Delays
Kilo 141	48
FAL	Incompatible

M4A1	48
FR 5.56	59
Oden	Incompatible
M13	48
FN Scar 17	53
AK-47	42
SMGS	
AUG	58
P90	Incompatible
MP5	62
Uzi	52
PP19 Bizon	59
MP7	52
LMGS	
PKM	231
SA87	80
M92	208
MG34	Incompatible
Marksman Rifles	
EBR-14	48
MK2 Carbine	Incompatible
Kar98K	Incompatible

Fast reload programming unit delays for COD BO4:

Assault Rifles	Delays
ICR - 7	48
RAMPART 17	62
KN-57	56
VAPR - XKG	54
MADDOX RFB	63
Submachine Guns	
MX9	51
GKS	49
SPITFIRE	57
CORDITE	70
SAUG 9MM	47
Light Machine Guns	
TITAN	155

HADES	107
VKM 750	178

Tactical Rifles

SWORDFISH	69
ABR 223	61
AUGER DMR	62

Fast reload programming unit delays for COD WW2:

Rifles	Delays
M1941	59
M1GARAND	44
STG44	46
M1A1CARBINE	55
FG42	66
BAR	46
SVT-40	56

Submachine Guns

GREASE GUN	43
PPCH-41	49
TYPE 100	43
WAFFLE 28	46
M1928	43
MP-40	43

Light Machine Guns

LEWIS	172
MG 15	149
BREN	172
MG 42	173

fast reload programming unit delays for cod infinite warfare:

Assault Rifles	Delays
NV4	52
R3K	Incompatible
KBAR-32	58
Type-2	60
Volk	60

Submachine Guns

--	--

Erad	57
FHR-40	58
Karma-45	46
RPR Evo	63
HVR	51

Light Machine Guns

R.A.W.	94
Mauler	148
Titan	85

Classic

OSA	52
MacTav-45	50

fast reload programming unit delays for cod4 modern warfare remastered:

Assault Rifles	Delays
M16A4	52
AK-47	52
M4 Carabine	52
G3	52
G36C	52
M14	52
MP44	52

Submachine Guns

MP5	60
Scorpion	75
Mini-Uzi	75
AK-74U	52
P90	61

Light Machine Guns

M249 SAW	181
RPD	201
M60E4	238

fast reload programming unit delays for cod black ops 3:

Sub Machine Guns	Delays
Kuda	43
VMP	43

Weevil	50
Vesper	47
Pharo	52
Razorback	43

Light Machine Guns

BRM	173
Dingo	150
Gordon	173
48 Dredge	173

Assault Rifles

KN-44	46
XR-2	42
HVK-30	46
ICR-1	46
Man-O-War	61
Sheiva	56
M8A7	47

fast reload programming unit delays for cod ghosts:

Assault Rifles	Delays
SC-2010	50
AK-12	60
Sub Machine Guns	
CBJ-MS	64
Vector CRB	42
Light Machine Guns	
Ameli	145
LSAT	177
Chain SAW	175
Marksman Rifles	
IA-2	57
SVU	50
Sniper Rifles	
USR	68
Lynx	77
VKS	65

Shotguns

IMPORTANT: *If you don't see your weapon in the chart, it means it is incompatible with the Fast Reload mod.*

Having issues operating your Mega Modz Controller? Visit our [Community Forums](#) for troubleshooting.