



MEGA MODZ REMAPPABLE BUTTONS

WHAT ARE RE-MAPPABLE BUTTONS?

Two extra back buttons can be installed on the controller, and these buttons can be remapped to perform the function of any stock button. For example, the re-mappable button can be set up to control the Cross button, so that any time the user presses the re-mappable button, the mod presses the Cross button for them. Remappable buttons are normally used so that the player doesn't have to move their thumbs away from the thumbsticks during gameplay.

Remappable buttons are compatible with any game on the market.

Back buttons can be used while controller modes are activated.

HOW DO PROGRAMMABLE MIMIC BUTTONS WORK?

If you have programmable buttons, you can change the assignment of your buttons through the programming menu.

- *Hold mod switch + tap PS Home button to enter the mod programming menu. All four LED's will turn white, and then the mod waits for you to enter a selection.*
- *Press any re-mappable button to program it, and the four LED's will blink once slowly to let you know it's ready for your selection.*
- *Then press any stock button. The four LED's will blink twice to confirm that it accepted your selection.*
- *To configure another re-mappable button, press the other back button (mod will blink slowly once) and then press the stock button you want to assign to that remappable button (mod will blink twice).*
- *When you're all done configuring your back buttons and are ready to save your changes, hit the mod switch. All four LED's will blink quickly three times to confirm that your new settings were saved, Mod will then exit the programming menu.*