JITTER

Navigate To:

What Is Jitter Mod?

Jitter mod allows users to shoot burst-fire weapons as fully auto ones for the ultimate firepower.

How Does Jitter Mod Work?

When using any burst firing weapon, activated Jitter Mod decreases the time between bursts, making guns shoot faster. Jitter Mod is effective at close range, but it might reduce the accuracy at long range. Once a rifle is scoped IN, you can use normal firing. Jitter Mod was patched in MW3 and BO3.

Jitter Mode and Rapid Fire feature cannot be used simultaneously.

How Do I Operate Jitter Mod?

First, you must turn the Jitter ON.

To enable the Mod on your controller:

- **Hold the mod switch, then press and hold the Right Bumper (In Default Button Layout), and tap the Button Y. LED 2 will illuminate to let you that Jitter has been enabled.**

To change Jitter sub-modes:

- **Make Sure Jitter Mod is ON.**

- **Hold the mod switch, then press and hold the Right Bumper (In Default Button Layout), and then hold Button Y.**

- **LED 2 will blink. Count the number of blinks on LED 2 and release the buttons when you arrive on the mode you want.**

Eight Jitter sub-modes are available:

- **Mode 1: "7" speed number. Jitter YY glitch.**

- **Mode 2: "7" speed number. Jitter YY glitch. While scoped, jitter turns off.**

- **Mode 3: "7" speed number. Jitter XYY glitch.**

- **Mode 4: "7" speed number. Jitter XYY glitch. While scoped, jitter turns off.**

- **Mode 5: "255" speed number. Jitter YY glitch.**

- **Mode 6: "255" speed number. Jitter YY glitch. While scoped, jitter turns off.**

- **Mode 7: "136" speed number. Jitter XYY glitch.**

- **Mode 8: "136" speed number. Jitter XYY glitch. While scoped, jitter turns off.**

To toggle Jitter Mod OFF:

- **Hold down mod switch on the back and then tap Y Button. The LED2 will turn off.**

What Games Is Jitter Mod Compatible With?

Jitter Mod compatible with all Call of Duty Games except BO3, Advanced Warfare and Modern Warfare 3.